

## IMPORTANT SAFEGUARDS

To guard against injury, basic safety precautions should be observed including but not limited to the following;

- The transformer is under no circumstances intended to be placed in the pond or water feature, it must therefore be located within three meters of the pond or water feature in a suitably dry and protected position. It should be out of direct sunlight and preferably mounted at least 30cm above ground level.
- Do not operate the light if the light or any of its components of the light such as the cord have been damaged in any way.
- Always use a properly grounded power supply that is connected to an RCD of less than 30mA. As per AS/NZS 3350.2.41:1997.
- Always unplug the light from the power supply when not in use or before performing any maintenance on the light. Never pull the cord to disconnect the plug from the power supply. Grasp the plug and pull to disconnect.
- Do not cut the cord as this will result in voiding your warranty.
- Care should be taken to arrange the power cord so that it cannot be accidentally tripped over or pulled.
- Do not attempt to repair the light yourself. Return to an authorized service centre or place of purchase if a fault occurs.
- Do not use in water above 35°C.
- Do not attempt to use this transformer on any other device without first verifying with Aquatec

## LIMITED WARRANTY

- Warranty covers only appliance defects and faulty material and workmanship within a 2 year period.
- Faults arising due to; accidents, misuse, not following manufacturer's guidelines/ instructions or power surges/spikes/brownouts will not be covered.
- Warranty will be void if any tampering removal of warranty labels or electrical is evident.
- Loss of livestock, damage to property or personal injury caused by this product will not be covered
- Warranty will be void if power cord is cut or damaged in any way.
- Warranty claims caused by installation faults will not be covered.
- It is the customer's responsibility to return the faulty appliance for any warranty claim, to Aquatec.
- For any warranty to be valid, an original proof of purchase must be provided.



## LED POND LIGHT



## INSTRUCTIONS MANUAL

Manufactured for:

**AQUATEC EQUIPMENT**

PO Box 648, Maddington, Western Australia, 6989

Telephone (08) 9452 2444

Email [info@aquatecequipment.com](mailto:info@aquatecequipment.com)

[www.aquatecequipment.com](http://www.aquatecequipment.com)



## LED POND LIGHT

12 LED RING LIGHT (ALL COLOURS)	
VOLTAGE (V)	12V
POWER (WATTS)	2.5W
CABLE LENGTH (M)	10M
DIMENSIONS (MM)	33MM DIAMETER (O/D)

Congratulations on your purchase of this great addition to your pond or water feature. Please check the list of parts to see that you have everything that should come in the kit.

### DESCRIPTION AND FEATURES

Your Aquapro LED pond light has been manufactured with advanced technology to provide you with the best quality lighting accessory for your pond.

- The Aquapro LED light is suitable for use in or out of water.
- The transformer converts the power supply to a safe 12volt for peace of mind in your garden.
- Dual hosetail to adapt to 12mm or 19mm tubing.

### INSTALLATION

- If required, have a qualified electrician install a weather proof power point near to the pond, (within 10 meters so the light cable will reach the transformer.
- Mount the transformer in a dry and protected location making sure that it can't be wet by either rain or reticulation.
- Connect desired hosetail to the LED ring by pushing on to base of LED ring, connect tubing to hosetail and position in desired location.
- Connect cable to transformer taking care it does not get wet.
- Connect power cable to a powerpoint and turn on the power to the transformer.

### MAINTENANCE

There is minimal maintenance requires on the LED pond lights, the light should be inspected on a regular basis to ensure the light or cable is not damaged in any way.

The light should be cleaned regularly to ensure maximum efficiency.

